

OnCue[®] Plus

QUICK-START GUIDE

**WELCOME TO ONCUE® PLUS.
WE'D LIKE TO SHOW YOU AROUND.**

With OnCue Plus remote monitoring, you can manage your generator from anywhere in the world. And this easy guide will show you how to get started.



STEP 1: **DOWNLOAD THE APP**

First things first: visit the App StoreSM or Google PlayTM, and search “KOHLER® OnCue Plus.” Then download the OnCue Plus app to your mobile device.




Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play and the Google Play logo are trademarks of Google Inc.

STEP 2: CREATE AN ACCOUNT OR LOG IN

When you open your app, you'll be asked for a username and password. If you already created an account, you can log in now. If you need to create an account, tap the "Create Account" link. Fill out the information, then we'll send you an email to activate your account. Once your account is activated, log in to the OnCue® Plus app.




The screenshot shows the login screen of the KOHLER Generators OnCue Plus app. At the top, the status bar displays "Carrier" with a signal strength icon, the time "4:00 PM", and a battery level icon. The app title "KOHLER Generators OnCue Plus" is centered in white text. Below the title are two white input fields: the first is labeled "USERNAME" and the second is labeled "PASSWORD". Underneath the password field is a checkbox labeled "REMEMBER ME" which is checked. Below the checkbox are two buttons: a green "LOG IN" button and a white "DEMO" button with a dark border. At the bottom of the screen, there are three links: "Forgot Password", "Create Account", and "Send Feedback".


STEP 3: ADD YOUR GENERATOR

Once you're in the app, the first thing you need to do is add your generator. See below.

First, tap the menu icon in the top left.




Then tap the "ADD NEW GENERATOR" button, and follow the instructions. You'll need your generator's serial number and OnCue® Plus password.




STEP 4: ACTIVATE YOUR GENERATOR

Now that your generator is added, there's only one thing left: activate your generator. Then you're ready to use OnCue Plus.

First, tap the menu icon in the top left.



Find your generator, tap the "ACTIVATE YOUR GENERATOR" link and follow the instructions.





CONGRATULATIONS!

You're ready to start OnCue® Plus. Enjoy.

HOW TO USE ONCUE® PLUS.

Along the bottom of your screen is your navigation bar. This is where you'll find everything you need to know about your generator.





STATUS

Status is the default screen when you open OnCue® Plus. The power icons in the middle of this screen indicate where your power is coming from: the utility or your generator.

Carrier 8:48 AM

OnCue.Plus

EVENT HISTORY

| TIME | DESCRIPTION | CLEAR ACTIVE |
|----------|----------------------------------|--------------|
| 510d ago | Warning: Not In Auto | > |
| 510d ago | Status: Available Source2 Vol... | > |
| 510d ago | Status: Engine Started | > |
| 510d ago | Status: Ats Test Active | > |
| 510d ago | Status: Engine Stopped | > |
| 510d ago | Status: Unavailable Source2 | > |
| 510d ago | Warning: Not In Auto | > |
| 510d ago | Status: Ats Exercise Ended | > |
| 510d ago | Status: Available Source2 Vol... | > |
| 510d ago | Status: Engine Started | > |

Status
 Events
 Control
 Exercise
 More

EVENT HISTORY

This page keeps you up-to-date on the health of your generator. It gives you a detailed list of the events the generator experiences including exercises, faults and warnings. Just tap on an event to see its details. OnCue Plus can even send you an email if there's a problem.

Carrier 1:02 PM

OnCue.Plus

CONTROL

START

Exercise

| | |
|------------------------------------|--------------------------|
| SMITH FAMILY Device Name | 3599 RPM |
| Unloaded Full ... Exercise Type | 60.0 Frequency |
| Not Scheduled Next Exercise | 214.5/12V Gen/Battery |

| PIM | | LOAD SHED |
|-----|-------------------------|-----------|
| 1 | Digital Output B1 Value | OFF |
| 2 | Digital Output B2 Value | OFF |
| 3 | Hot Tub | ON |
| 4 | Security System | ON |
| 5 | Yard Lights | ON |
| 6 | Sprinkler System | ON |

Status
 Events
 Control
 Exercise
 More



CONTROL

On the Control page, you can perform additional exercises remotely without affecting your weekly scheduled exercise. Turn on/off specific electronic appliances or rooms (available only when paired with a Programmable Interface Module [PIM]). And watch your generator automatically manage your power (available only with certain generator models).

• Perform additional exercises remotely without affecting your weekly scheduled exercise.

EXERCISE

Here you'll be able to keep track of your generator's exercise schedule to know it's running in top condition. You can manage the exercise interval, run duration and mode, even while you're away.



Carrier 8:49 AM

OnCue.Plus


PARAMETERS

| Name | Value |
|----------------------------|------------|
| Controller Type | Rdc2 |
| Current Firmware | 5.10.0 |
| Current Firmware | 6.11.2 |
| Engine Speed | 3599 R/min |
| Engine Oil Pressure | 0 Psi |
| Engine Coolant Temperature | 32 °F |
| Battery Voltage | 12 V |
| Lube Oil Temperature | 147.0 °F |

Status
 Events
 Control
 Exercise
 More

PARAMETERS


These pages let you view over 20 generator parameters that offer detailed information such as firmware version number, serial number and power output.



DEALER

Have a question or want to set up a service appointment? Your personal KOHLER dealer is just a tap away.

Your KOHLER dealer will set up this page during the OnCue® Plus installation.



SETTINGS

Manage your email notification list. Change the labels of your power outputs. Edit your generator settings and more. All right here.

- **Personalize the names of your outputs (available with PIM and/or LCM options).**





KOHLER®
IN POWER. SINCE 1920.

KohlerGenerators.com

PRINTED IN U.S.A.

G18-247 11/16

© 2016 KOHLER CO.